

Nortel Phone Instructions (Delete Mailbox)

Feature 983

LOG: 120000 (2 digit ext's example 21) or 1020000 (3 digit ext's example 221) or 10020000 (4 digit ext's example 2221) or replace the 0000 with the password I gave you.

Press OK

Press MBOX

Press DEL

<Display> MBOX:

Enter Mail Box Number you wish to
DELETE

**(NOTE: ANY MESSAGES IN THE MAIL
BOX WILL ALSO BE DELETED!!!!)**

<Display> <NAME>

Press DEL

<Display> Mailbox Deleted

Press Rls